TIRE & WHEEL

Removing/Installing Wheel (2) Removing/ Installing Wheel Nuts



●1/2"sq. Wheel nut socket set for impact wrench (long, thin type) PAT.P.



1/2"sq. SOCKET SET FOR ALUMINUM WHEEL



1/2"sq. WHEEL NUT SOCKET

WHEEL NUT SOCKET SET FOR IMPACT WRENCH

No. TBP4803 Wheel nut socket for impact wrench

🖰 1 580 BP48-17, 19, 21

| No. | S (Hexagonal) | D 1 | D ₂ | н | l | L | | Ð | |
|---------|---------------|------------|----------------|----|----|-----|-----|---|--|
| BP48-17 | 17 | 24.0 | 25 | 22 | 18 | 100 | 180 | 5 | |
| BP48-19 | 19 | 26.0 | 25 | 24 | 18 | 100 | 200 | 5 | |
| BP48-21 | 21 | 27.5 | 25 | 26 | 18 | 100 | 200 | 5 | |
| BP48-22 | 22 | 29.5 | 25 | 27 | 18 | 100 | 220 | 5 | |

POWERFIT

POV

POWERFIT

Usage

Compatible with exclusive socket wrenches and impact wrenches used to tighten and loosen vehicle wheel nuts.

Characteristics Exclusive socket for the aluminum wheel

· A protective rubber cushion has been fitted for chrome or painted nuts. OD NOT USE EXCEPT FOR CAR WHEEL NUTS.
 SECIALLY DECIDING THAS DEED THE AND THE

SPECIALLY DESIGNED TO BE THINNER THAN ORDINARY PRODUCTS. DUE TO THE THINNER CONSTRUCTION, THIS SOCKET SET MAY BREAK DEPENDING ON THE WAY OF USE.


SOCKET FOR ALUMINUM WHEEL

| No. | S (Hexagonal) | D 1 | D ₂ | н | l | L | | ₿ | |
|----------|---------------|------------|----------------|----|----|----|-----|----|--|
| B35A-17H | 17 | 24 | 21 | 22 | 15 | 60 | 140 | 10 | |
| -19H | 19 | 26 | 21 | 24 | 15 | 60 | 140 | 10 | |
| -21H | 21 | 27.5 | 21 | 27 | 15 | 60 | 140 | 10 | |

Purpose

- Specialty for fasten/loosening aluminum wheel nuts of cars.
- With rubber cushion for plated and painted wheel nut.

DESIGNED SPECIALLY FOR THE ALUMINUM WHEEL AND ENDURES LOWER TORQUE BECAUSE OF ITS STRUCTURE.



| No. | S (Hexagonal) | D 1 | D ₂ | н | L | | Ø | |
|----------|---------------|------------|----------------|----|-----|-----|---|--|
| B38Z-17H | 17 | 24 | 22 | 22 | 100 | 200 | 5 | |
| -19H | 19 | 26 | 22 | 24 | 100 | 200 | 5 | |
| -21H | 21 | 27.5 | 22 | 26 | 100 | 200 | 5 | |
| -22H | 22 | 29.5 | 22 | 27 | 100 | 200 | 5 | |

Specially for fasten/loosening aluminum wheel nuts of cars.

Features

- The whole length is 100mm, designed exclusively to fit the wheel. Use with a torque
- wrench improves work efficiency.With rubber cushion for plated and painted wheel nut.
- 22H is for Land Cruiser 100 and Honda Legend (KB1)





●1/2"sq. WHEEL NUT LONG SOCKET




WHEEL NUT LONG SOCKET

| No. | S (Hexagonal) | D 1 | D ₂ | н | L | | ₿ | |
|-----------|---------------|------------|----------------|----|-----|-----|---|--|
| B38ZL-17H | 17 | 24 | 24 | 22 | 180 | 330 | 5 | |
| -19H | 19 | 26 | 24 | 24 | 180 | 340 | 5 | |
| -21H | 21 | 27.5 | 24 | 26 | 180 | 350 | 5 | |

Purpose

· Specially for fasten/loosening aluminum wheel nuts of cars. Features

Long size most appropriate for RVs.
Long size necessitates no extension bar and improves work efficiency.
With rubber cushion for plated and painted wheel nut.



CROSS RIM WRENCH



WHEEL NUT TORQUE WRENCH SET

| No. TWCMPA221 | kg 1.3 | H 1 | |
|--|---------------|------------|--|
| 1/2"sq. Torque wrench for wheel nut | | WCMPA103 | |
| 1/2"sq. Exclusive socket for wheel nut 2 | 1mm | B38Z-21H | |

- Usage
 This tool is a pre-set type torque wrench that is used to tighten vehicle wheel nuts 17, 19, and 21mm at a specified torque of 103N-m (10.5kgf-m). (The 17, 19mm sockets are
- sold separately.) Applicable for clockwise rotation tightening. (Is not applicable for anti-clockwise rotation tightening)

Characteristics

- Reliable operation is possible through torque management. (For confirmation during
- inspection on completion) Work hours have been reduced with the employment of the ratchet head. (36 plate
- The full optimum length is designed so that the tire and the mechanic's hands do not interfere. (Full length has been set at 420mm, 55mm longer than in previous models.)
- The load on the handle has also been reduced during operation. The head angle changes with a light shock to the hands when the tightening torque is reached, enabling recognition of completion.
 The rubber cap attached to the base prevents entry of dirt and dust.
 Provided with a soft case that makes storage easy.

*Replaceable parts are available for the ratchet section. Check with your dealer for details

Compatibility Table (Domestic Vehicles)

| <u></u> | | | | | | | | |
|--|----------------------|---|--|--|--|--|--|--|
| Nut size (mm) | Manufacturer | Examples of Compatible Cars | | | | | | |
| 19 | Honda, Subaru | All passenger vehicles (except recreational and light vehicles) | | | | | | |
| *19mm socket is required (sold separately) | Isuzu | All passenger vehicles | | | | | | |
| | Toyota, Nissan | All passenger vehicles (except recreational and light vehicles) | | | | | | |
| 21 | Mitsubishi, Daihatsu | All passenger vehicles (except recreational and light vehicles) | | | | | | |
| | Mazda | All passenger vehicles (except recreational and light vehicles) | | | | | | |

The torque value for light vehicles with 17mm nuts differs from the one for regular vehicles. For this reason, the torque wrench above cannot be used. However, the torque wrench can be used on some foreign cars made outside of Japan. Compatible with wheel tightening torque value of 103N·m. (Not applicable to certain

vehicles and wheels.) The wrench cannot be used for trucks and recreational vehicles, as the torque value

- required is too high
- Check the torque value before using wrench on non-standard wheels.

1. This torque wrench is exclusively designed for wheel CAUTION nuts. Do not use this tool to tighten or loosen other bolts/nuts. 2. The wheel tightening torque is set for domestically manufactured vehicle standard wheels. Check the


- torque settings for special wheels before use. 3. This product is a measurement tool. Take extreme care when handling. Be sure to avoid dropping, throwing, or
- hitting this product. 4. Hold the grip at the line as the center and apply even firm pressure.
- 5. Applying pressure at other places (pipe part etc.) than the grip will give inaccurate torque readings.

●1/2"sq. WHEEL NUT **TORQUE WRENCH SET**

D.PAT.

Inspecting Tightening Torque Δ





Confirm the tightening torque with the wrench positioned between the arrows as shown in the diagram.

- 6. Use this product multiple times to avoid misleading when the tool has been stored for a long time.
- 7.Do not use during rain, high humidity levels, and in conditions where the tool is exposed to water. 8.Do not disassemble this product. The torque settings
- can become faulty.
- 9. Immediately stop use and request for an inspection/disassembly and adjustment when this product is dropped, submerged in water, emits abnormal sound, or operates faultily.
- 10.Do not apply force after operation.