HANDY BAR									
No.	Name	w	Т	L	▼g	#			
LZ2-330	Handy Bar, Mini	19	10	330	530	5			
-420	Handy Bar, Short	9	10	420	635	5			
-600	Handy Bar, Long	19	10	600	800	5			

Purpose


Prying Widening For adjusting tension belts such as V-belt For removing missons from engines For separating struts and lower arms Drawing

For drawing drive shafts from missions (def): For removing oil seals, gears, bearings, etc.



ROLLING WEDGE BAR								
No.	Shank Dia.	L	▼g	#				
LZ1-450	ø16	410	685	1				

[•] Convenient tool aligning, prying, widening, hitting, etc.




SERVICE CREEPER								
No.	L	w	Н	h	Special Features	▼kg	#	
AYSC-20F	1030	440	105	85	6 wheels type for superb operationability Big sized head rest applied for easy operation	7.5	1	
-20R	1030	440	125 ~240	90	Made of sponge Made of urethane with head rest	8.5	1	

[·] All items have swivel castors for good movability.




- DO NOT USE ANY CASTORS WHICH ARE WEARED, OLD OR CANNOT TURN
 - DO NOT USE ON ANY SLOPE AND/OR ROUGH SURFACE.



*Castors are set as replacement parts. Check with your dealer for details.



SERVICE CREEPER



FENDER COVER								
No.	Size	▼g	#					
AYC-2	400×1100	750	1					

Features

- Built-in magnet rubber in 4 positions make attachment to fender easy.
- With folding (stitches) easy to set on the fender.
- Inside is made of soft cloth that does not hurt the body, while outer surface is soft vinyl leather which absorbs shock.
- Work on car suspension possible even when the cover is on. Long enough to cover long nose cars.



- CAUTION DO NOT USE IN PLACES WHERE MAGNETISM MAY AFFECT ELECTRONIC
 - PARTS, ETC.

 MAGNET RUBBER PART TENDS TO COLLECT STEEL POWDER. REMOVE THE POWDER BEFORE USE.

• FENDER COVER

